

DA Installationsvejledning
Vigtigt! Læs brugsanvisningens instruktioner vedrørende sikkerhed, før installationen påbegyndes.



Kun tilgængeligt for visse modeller.

EN Installation Instruction
Warning! Before proceeding with installation, read the safety information in the User Manual.



Available only on some models.

FI Asennusohjeet
Varoitus! Ennen kuin aloitat asennuksen, lue käyttöohjeen sisältämät turvallisuusohjeet.



Saatavilla vain joihinkin malleihin.

NO Monteringsanvisning
Advarsel! Les sikkerhetsinformasjonene i bruksanvisningen før du begynner installasjonen.




Bare tilgjengelig på enkelte modeller.


SV Installationsanvisningar
Varning! Läs säkerhetsanvisningarna i bruksanvisningen innan du fortsätter med installationen.





Finns endast på vissa modeller.



20 mm





T20





H07 RN-F
H05 RN-F
H05 RRF
H05 W-F
H05 V2V2-F (T90)
H05 BB-F







1




850-859 mm	h1	+	H1
859-867 mm	h2	+	H2
867-876 mm	h1	+	H2
876 mm	h2	+	H3
876-885 mm	h2	+	H3
885-894 mm	h1	+	H3
894-902 mm	h2	+	H4
902-911 mm	h1	+	H4
911-920 mm	h2	+	H5
920-936 mm	h1	+	H5


2




3




4a



4b



5



H>920 mm

